


INSTRUCTION MANUAL

The functions that will be altered by updating the firmware are described here.

Widget and Application Operation

SNS Widget

- 1 Press the <HOME> button.
- 2 Flick the screen left or right to select the Service panel.
- 3 Touch [].
- 4 Select the SNS Widget.







Articles you posted or shared are displayed.



The Web browser starts and the Facebook Web site is displayed.

Facebook (SNS Application)

- 1 Press the <HOME> button.
- 2 Flick the screen left or right to select the Network contents panel.
- 3 Touch [].
- 4 Touch [ SNS].
- 5 Touch [ (Facebook)].
- 6 Perform desired operation as follows.



2 Article list

Articles you posted or shared are displayed.

Touching this displays details.



While the latest information is displayed at the top, sliding the list down updates the information.


: Reads out the article by voice.



The Web browser starts and the Facebook Web site is displayed.


Facebook (web browser)

- 1 Press the <HOME> button.
- 2 Flick the screen left or right to select the Service panel.
- 3 Touch [].
- 4 Select the SNS Widget.
- 5 Touch [].
- 6 Enter the Email address/Phone and Password.



7 Touch [Log in].

You have logged in to the Facebook Web site.



Note

- You can save the ID and password to the Web browser.

Network Media History Widget

This function is deleted.





Streaming Service Application

AV Browser Application

This is newly added app of dedicated Web browser to play back streaming video and audio.

Preparation

- You need to connect to Internet.

- 1 Press the <HOME> button.
- 2 Flick the screen left or right to select the Network contents panel.
- 3 Touch [].
- 4 Touch [ AV Browser].



Icons linked with web sites are displayed.




The portal site which shows recommended streaming services is displayed.




The list of tabs is displayed.

Play video and audio

- 1 Select the content you want to play.



- 2 Play the content.





- 3 Press the <↔> button to previous screen.


Note

- The instruction above is an example of operation. Actual operation is depended on the streaming service.

Streaming Video Application


This function is deleted.

- 1 Press the <HOME> button.
- 2 Flick the screen left or right to select the Network contents panel.
- 3 Touch [].
- 4 Touch [ Streaming Video].



Setting Up


System Setup



Demo mode

This function is deleted.

Functions of the Buttons



Name	Motion
▼, ▲ (Vol)	Adjusts volume. The volume will go up until 15 when you keep pressing [▲].