


INSTRUCTION MANUAL

The functions that will be altered by updating the firmware are described here.

Widget and Application Operation

SNS Widget

- 1 Press the <HOME> button.
- 2 Flick the screen left or right to select the Service panel.
- 3 Touch [].
- 4 Select the SNS Widget.







Articles you posted or shared are displayed.



The Web browser starts and the Facebook Web site is displayed.

Facebook (SNS Application)

- 1 Press the <HOME> button.
- 2 Flick the screen left or right to select the Network contents panel.
- 3 Touch [].
- 4 Touch [ SNS].
- 5 Touch [ (Facebook)].
- 6 Perform desired operation as follows.



2 Article list

Articles you posted or shared are displayed.

Touching this displays details.



While the latest information is displayed at the top, sliding the list down updates the information.


: Reads out the article by voice.



The Web browser starts and the Facebook Web site is displayed.


Facebook (web browser)

- 1 Press the <HOME> button.
- 2 Flick the screen left or right to select the Service panel.
- 3 Touch [].
- 4 Select the SNS Widget.
- 5 Touch [].
- 6 Enter the Email address/Phone and Password.



7 Touch [Log in].


You have logged in to the Facebook Web site.



Note

- You can save the ID and password to the Web browser.

Functions of the Buttons



Name	Motion
▼, ▲ (Vol)	Adjusts volume. The volume will go up until 15 when you keep pressing [▲].